

With sealing boot in correct position on axle shaft, proceed as follows.

STEP 1: Loop clamp band around boot twice, with boot passing through retainer each time a loop is completed.



STEP 2: Feed extra length of band into small end of boot clamp tool. NOTE: The open side of the tool must be facing up. Slide slotted bolt through the holes in the side of the main body, as shown in photo above. Band will pass through the slotted portion of the nut.




STEP 3: Place a wrench on the nut and draw the band up tight; then torque nut to 65 inch pounds as shown in photo above.



655 Eisenhower Drive
Owatonna, MN 55060 USA
Phone: (507) 455-7000
Tech. Serv.: (800) 533-6127
Fax: (800) 955-8329
Order Entry: (800) 533-6127
Fax: (800) 283-8665
International Sales: (507) 455-7223
Fax: (507) 455-7063



STEP 4: Turn tool over to bend band over lock tangs of clamp, as shown in photo above. Do not let band slip back through tool, because this will decrease clamping force.



STEP 5: Back tool off just enough to permit tapping the band with a hammer until it lies flat across the top of the retainer, as shown in photo above. Tap the tabs of the retainer down until they fasten the strap securely, as shown in photo below.




STEP 6: Unwind the excess bands, and cut it off close to retainer.


No. 7085 Boot Clamp Installer

With sealing boot in correct position on axle shaft, proceed as follows.

STEP 1: Loop clamp band around boot twice, with boot passing through retainer each time a loop is completed.



STEP 2: Feed extra length of band into small end of boot clamp tool. NOTE: The open side of the tool must be facing up. Slide slotted bolt through the holes in the side of the main body, as shown in photo above. Band will pass through the slotted portion of the nut.




STEP 3: Place a wrench on the nut and draw the band up tight; then torque nut to 65 inch pounds as shown in photo above.



655 Eisenhower Drive Owatonna, MN 55060 USA Phone: (507) 455-7000 Tech. Serv.: (800) 533-6127 Fax: (800) 955-8329 Order Entry: (800) 533-6127 Fax: (800) 283-8665 International Sales: (507) 455-7223 Fax: (507) 455-7063



STEP 4: Turn tool over to bend band over lock tangs of clamp, as shown in photo above. Do not let band slip back through tool, because this will decrease clamping force.



STEP 5: Back tool off just enough to permit tapping the band with a hammer until it lies flat across the top of the retainer, as shown in photo above. Tap the tabs of the retainer down until they fasten the strap securely, as shown in photo below.



STEP 6: Unwind the excess bands, and cut it off close to retainer.