














# CHRYSLER, DODGE, JEEP, AND RAM TRUCKS SPECIALTY TOOLS

BEST-SELLING TOOLS FOR SERVICING SOME OF THE NATION'S MOST POPULAR VEHICLES

	TOOL	APPLICATION	USE
6780	 Fuel Pressure Test Adapter	For use on 2003-Later 5.9L Cummins Diesel.	Adapts to fuel system for use during pressure testing and diagnostic procedures. Similar to MLR-9011.
6661	 Ball Joint Remover	Universal design to fit many applications including various 2003-Later Chrysler vehicles.	Designed to separate mainly the lower ball joint from the steering knuckle. Similar to MLR-8677.
6640	 Strut Nut Socket	Vehicles with Electronic and Passive type shock absorbers, including: <ul style="list-style-type: none"><li>• Ram Truck 1500 2006-Later</li><li>• Chrysler 2006-Later 200, Avenger, Sebring, Town &amp; Country</li><li>• Dodge 2006-Later Challenger, Charger, 300, 300C, Magnum, 2008-Later Caravan, Grand Caravan, Journey</li><li>• Jeep 2006-Later Compass, Patriot, Caliber, Grand Cherokee</li><li>• Mitsubishi 2006-Later Outlander and Raider</li></ul>	For use on shock absorbers that have the electrical terminals coming through the center of the tenion and the mounting nut deep into the top mount. A typical socket cannot be used in this application. Tenion must be held with a 9mm open end wrench. This design will allow this interaction to ease the repair. This tool will also work with Passive Absorbers. Hex Size; 18 mm. 1/2" Square Drive. Similar to CH-50732-A and MLR-9362.
6670	 Valve Spring Compressor	Applications include Chrysler, Mitsubishi, and VW Routan engines. <ul style="list-style-type: none"><li>• Chrysler 2012-Later 1.4L, 2012-2013 1.4 Multiair, 2006-2007 1.6L, 2006-2013 2.0L, 2014 2.0L Diesel, 2006-2010 2.4L, 2013-Later 2.4L, 2006-2010 2.7L, 2006-2014 2.8L Diesel, 2006-2010 3.0L Diesel, 2014-Later 3.2L, 2006-2010 3.5L, 2011-Later 3.6L, 2007-2011 4.0L, 2006 8.3L, 2008-2010 8.4L, 2013-2017 8.4L.</li><li>• Mitsubishi 92-Later 3.0L, 3.3L, 3.5L, 3.8L, 5.2L, 8.0L and more engines.</li></ul>	A special tool and adapters to properly service valve train components during engine service when cylinder head is on the engine block. Similar to MLR-MD998772A.
6354	 Return Spring Compressor	For use on 1989-Later A-604, 41TE, 41AE, 42LE automatic transaxle. Also used on 42RLE transmissions.	This tool is used to compress the 2-4 piston return spring during removal or installation of the retaining ring in automatic transaxles. Similar to MLR-5058A.



	TOOL	APPLICATION	USE
	<b>6355</b> Crank Sprocket Installer	For use on Chrysler engines: <ul style="list-style-type: none"> <li>• 2006 2.0L DOHC</li> <li>• 2006-2010 2.4L, 2.7L, 3.2L, 3.5</li> <li>• 2007-2011 4.0L</li> </ul>	Used to install the crankshaft sprocket. Hardened forcing screw may also be used to replace the original 12mm bolt. Includes additional bolt for the 2.7L engine. Similar to MLR-6792 & MLR-8179.
	<b>6356</b> Crank Sprocket Remover	For use on Chrysler engines 2006 2.0L and 2006-2010 2.4L engines.	Specialized puller for removing the crankshaft sprocket. Includes three (3) 6mm x 1 x 50mm bolts. Similar to MLR-6793.
	<b>6782</b> Fuel Tank Leak Check Adapter	Applications include: <ul style="list-style-type: none"> <li>• 2006-Later Chrysler/Dodge/Jeep vehicles</li> <li>• 1999-2003 Mitsubishi Gallant</li> <li>• 2001-2005 Mitsubishi Eclipse Spyder</li> </ul>	A gas tank and gas cap adapter for diagnosing tanks with 1/4 turn type fuel filler caps. Designed to be used with EVAP system tester. Includes a male tank adapter and female cap adapter connected by a 20" hose. Similar to MLR-8382.
	<b>6783</b> Fuel Tank Leak Check Adapter	<ul style="list-style-type: none"> <li>• Chrysler 2006-Later Pacifica, Aspen, 200, 200 Convertible, Sebring, Sebring Convertible, 300, 300C, PT Cruiser</li> <li>• Ram Truck 2006-Later</li> <li>• Dodge 2006-later Durango, Avenger, Nitro, Charger, Magnum, Caliber, Dakota, Sprinter</li> <li>• Jeep 2006-Later Wrangler, Liberty, Compass/Patriot, Grand Cherokee, Commander</li> <li>• Chrysler 2008-Later Town &amp; Country</li> <li>• Dodge 2008-Later Grand Caravan, Challenger, Journey</li> <li>• Fiat 2008-later 500L, Freemont</li> </ul>	A gas tank and gas cap adapter for diagnosing tanks with conventional threaded type fuel filler caps. Designed to be used with EVAP system tester. Includes a male tank adapter and female cap adapter connected by a 40" hose. Similar to MLR-6922.
	<b>6358</b> Alternator Decoupler Pulley R/I	Applications include 2004-Later Chrysler/Dodge/Jeep vehicles.	This tool holds the alternator shaft in place so the decoupler pulley can be removed and installed. Male and female ends are 10mm. Similar to MLR-8433A.
	<b>6359</b> Power Steering Pulley Puller	<ul style="list-style-type: none"> <li>• Chrysler 2006-2008 Pacifica, Sebring, Town &amp; Country</li> <li>• Jeep 2006 - 2008 Liberty, Wrangler</li> <li>• Dodge 2006 - 2008 Stratus, Caravan, Grand Caravan PT Cruiser</li> <li>• Plymouth 2006 - 2008 Grand Voyager, Voyager</li> </ul>	Designed for use on power steering pump pulley to prevent damage during pump and pulley removal. Also used to remove alternator pulley on Chrysler vehicles. Similar to MLR-C-4333A.