



655 Eisenhower Drive  
 Owatonna, MN 55060 USA  
 Phone: (507) 455-7000  
 Tech. Serv.: (800) 533-6127  
 Fax: (800) 955-8329  
 Order Entry: (507) 455-1480  
 Fax: (800) 283-8665  
 International Sales: (507) 455-7223  
 Fax: (507) 455-7746


Form No. 102370

**Parts List &  
 Operating Instructions**  
 for:

7106

**Cylinder Liner Height Gauge**  
*(with hold-down bar)*

**Parts List**




Item No.	Part No.	No. Req'd	Description
1	39431	1	Hold-down Bar
2	205655	1	Dial Indicator
3	39432	1	Gauge Bar
4	205715	1	Thumb Screw
5	205702	2	Hex Hd. Cap Screws (11/16-16 UN-2A)
6	10024	2	Hex Hd. Cap Screws (1/4-20 x 1-3/4 Lg.)
7	205653	2	Drilled Spacers
8	205652	2	Tapped Spacers
9	24826	4	Washers


**Operating Instructions**

- Center the hold-down bar over the liner. See Figure 1.
- Tighten bolts evenly. (Item #5 cap screws are supplied for Cummins applications.)  
**CAUTION: To prevent equipment damage, do NOT exceed 50 ft. lbs.**

*Note: On Detroit engines where the liner is beneath the block surface, adjust the two spacers to the correct bore diameter before bolting the hold-down bar to the block surface. See Figure 2.*



**Figure 1**



**Figure 2**

Sheet No. 1 of 1

Issue Date: Rev. B August 12, 2014

3. Place the gauge bar on the cylinder block, and dial the block surface to zero on the indicator. See Figure 3.



**Figure 3**

4. Move the gauge block to the liner, and measure the protrusion at four equidistant points. See Figure 4.
5. Refer to the manufacturer's specification for correct liner protrusion.



**Figure 4**