



655 Eisenhower Drive Owatonna, MN 55060 USA Phone: (507) 455-7000 Tech. Serv.: (800) 533-6127 Fax: (800) 955-8329 Order Entry: (800) 533-6127 Fax: (800) 283-8665 International Sales: (507) 455-7290 Fax: (507) 455-7063

Operating Instructions for:

1230PB 2036PB 2860PB

Protective Blanket

Safety Precautions

WARNING: To help prevent personal injury,



- A protective blanket should not be considered a total protection device. Other personal protective equipment (PPE), such as safety glasses (that meets ANSI Z87.1, CE EN166, AS/NZS 1337, and OSHA standards), safety shoes, and hard hats, must also be used. Stand away from the work area when applying force.
- Replace any protective blanket that is cut, torn, or damaged.
- Release the force from a workpiece before removing the protective blanket to look at or adjust the workpiece.
- The protective blanket can be used in many different applications. It is the responsibility of the user to determine the best method of protection.
- Do not store or use the protective blanket near heat in excess of 200° F (93° C).

Instructions

- 1. Check the protective blanket for cuts, tears, or damage; do not use the blanket if any of the conditions exist.
- 2. Wrap the blanket around both the workpiece and the tool. Secure the blanket in place with straps.

NOTE: Figures 1 and 2 are examples of how a blanket can be used. These photos show a clear blanket to help understand the use of blankets, however, clear blankets are not available. Our protective blankets are a solid, opaque color, and not see-through.

Figure 1 - blanket covers both the puller tool and the part being pulled.

<u>Figure 2</u> - blanket covers the housing, the bearing being installed, and the installing tool.





Figure 2

Preventive Maintenance

CAUTION: To help prevent equipment damage,

- Do not store or use the protective blanket near heat in excess of 200° F (93° C).
- Clean blankets as needed with a damp cloth and mild detergent. Do not use harsh chemicals or solvents.

Sheet No.	1 of 1	
Issue Date:	Rev. D	April 11, 2018